



PinPoint 3-PXle

Component-level diagnostics and high-performance functional testing in one system

Built on Performance

The PinPoint 3-PXle combines over 30 years of development of the PinPoint Circuit Card diagnostic system with industry standard PXle technology.

PinPoint provides a comprehensive suite of tools for identifying failures down to the component level, while PXle provides access to countless instruments that can be used to test a wide range of mixed signal products.

The PinPoint 3-PXle is the ideal solution for addressing unlimited test applications and troubleshooting to the component level, all from one system.

Supporting Legacy Equipment

- Test coverage to support aging testers
- Low cost rehosting capability from obsolete testers
- Tech data created for undocumented circuits
- Multi-level test strategy
- Functional testing from the edge connector
- Diagnostics to the component level
- Comprehensive fault coverage
- Rapid program development

KEY BENEFITS

- **SWPC Savings** – Diagnostics and full functional test in one system saves space, weight, power, and cost
- **Maximize ROI** – Suitable for legacy and modern technology
- **Keep Assets in Service** – Significantly reduce the number of No Fault Found (NFF)
- **Control System Maintenance** – Reduce dependence on OEMs, shorten repair cycle, lower maintenance cost
- **Easy Transition** – low cost rehosting capability
- **Versatility** – can be used on virtually any type of circuit card

IDEAL FOR USE ON:

- Avionics equipment
- Radar
- Weapons systems
- Military or commercial aircraft
- Ships

Key Features

PXIe 9-slot chassis (8 hybrid slots), features an all-hybrid backplane to meet a wide range of high-performance test and measurement application needs.

Hybrid slots for instrumentation flexibility = compatibility with PXI, PXIExpress, CompactPCI, and CompactPCI Express modules.

Performance—up to 8 GB/s system and 2 GB/s per-slot dedicated bandwidth.



Customizable for Your Test Needs

The P3-PXIe can be configured from a comprehensive selection of COTS instruments, power supplies and switches, making it an ideal test solution for a wide range of avionics, weapon system controls, and electronic assemblies.



...continued

With Open architecture, you get to choose from a wide range of commercially available instruments, ensuring you get the right balance of instruments to address your testing requirements.

Examples:

- Digital I/O (PXIe-6943 or 7820)
- Digitizers (PXIe-5775 or 5764)
- Analog Output (PXIe 6738)
- VST (PXIe-5841 or 5860)
- Avionics (1553/429/708/717)
- Dual Channel Pulse Gen (PXIe-1209)
- Rubidium Ref with GPS (PXIe-3352)
- Freq Time Interval Count (PXIe-2461)

A "Ready For Issue" (RFI) Solution

With the PinPoint 3-PXIe, you can achieve full functional test coverage for a wide range of Circuit Card Assemblies (CCA). Screening items that are suspect (i.e. ambiguity call out from the LRU test) reduces the number of No Fault Found (NFF) items and significantly lowers support costs. Additionally, having the ability to test an asset after it has been repaired shortens the repair cycle



PXIe 5841 / 5860



PXIe 6738



PXIe 5764



PXIe 6943

CHASSIS UPGRADE

PinPoint 2R owners can upgrade their current system and take full advantage of the P3-PXIe capability. By upgrading their PinPoint, customers retain all the pin electronics and protect their initial investment, while increasing the systems application coverage and versatility.

P3-PXIe

Combines the power of PinPoint with the flexibility of PXI – one system, endless possibilities.

Get Started Today

For additional details, please contact Astronics Test Systems.

12700 Ingenuity Dr.,
Orlando, FL 32826 USA
+1.407.381.6062
ATSales@astronics.com
Astronics.com